


PLAN VIEW

Notes:

1. Place curb type sediment barriers on gently sloping street segments, where water can pond and allow sediment to separate from runoff.
2. Sandbags of either burlap or woven 'geotextile' fabric, are filled with gravel, layered and packed tightly.
3. Leave a one sandbag gap in the top row to provide a spillway for overflow.
4. Inspect and repair sediment barriers and remove sediment after each storm event. Sediment and gravel must be removed from the traveled way immediately.

NOT TO SCALE

CITY OF MILPITAS, ENGINEERING DIVISION				STANDARD DRAWING NO. 474
REVISION	DATE	DESIGNED: MK	CURB INLET SEDIMENT BARRIER	
		DRAWN: JH		ORIGINAL: 8/24/05
		CHECKED: JH		DATE
		APPROVED BY: 	CITY ENGINEER	DATE: 8/24/05
				SHEET 1 OF 1